



Instruction Manual

Google TV™ Device - BPTV30



Enjoy it.

CONTENTS

General Safety	4
Product Overview	6
Setup	7
Remote Control	8
RC Pairing	9
First Time Setup	10
Google TV™ - Home	12
Google Assistant	14
Customer Helpline	Last Page

GENERAL SAFETY

Read this manual thoroughly before you start using this product.

Store this manual, the completed warranty card, your receipt and the product packaging.

Please follow all instructions and take notice of all warnings.

- Please beware that Dust could accumulate over time on the unit and cause it to generate heat and or deteriorate insulation, which in turn may result in an electrical fire.
- The product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or young children of any age, They must be supervised product by a person responsible for their safety.
- Batteries from the remote control must be only removed by an adult, the adult must ensure to keep them out of reach of infants and children. Seek medical attention immediately if a child has swallowed a battery.
- Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.
- Please ensure to contact our call center for any repair or service required for the products.

GENERAL SAFETY (CONT.)

Please make sure upon positioning this product, the place is:

- Not wet or damp and Well ventilated
- Away from direct sunlight or heaters.
- Away from splashes or food.
- Protected from excessive dust or grease.
- Do not install this product near heat sources such as radiators, stoves or other audio visual equipment that produce heat.




"HDMI, the HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC."

Google, Android, Google Play, YouTube and other marks are trademarks of Google LLC.

Manufactured under license from Dolby Laboratories. Dolby, Dolby Audio, and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.

PRODUCT OVERVIEW



-
- | | | | | | |
|---|-------------------|---|----------------|---|-----------------|
| 1 | ANDROID TV DEVICE | 2 | POWER ADAPTOR | 3 | MICRO USB CABLE |
| 4 | MANUAL/WARRANTY | 5 | REMOTE CONTROL | 6 | HDMI EXTENDER |

SETUP

Step 1

Plug in the Google TV device HDMI into the back of the TV HDMI Port on your TV.

Step 2

Plug in the Micro USB Power Cable (provided) into the side of the Google TV Device labeled. Then plug in the USB-A side into the power adaptor (provided) and then into a power outlet.

Step 3

Once you have connected the HDMI cable and power cable of the Google TV Device, make sure to change the TV input to the HDMI port you inserted your Google TV Device into.

Step 4

Now you can follow First time setup process of the Google TV Device.

Refer to page 8 for illustration.

REMOTE CONTROL


	Button	Description		Button	Description
01		POWER ON/OFF	09		SETTINGS
02		DIRECTION/NAVIGATION	10		HOME
03		OK	11		GOOGLE ASSISTANT
04		GO BACK	12		OPEN NETFLIX
05		OPEN LIVE TV EPH	13		OPEN YOUTUBE
06		VOLUME UP / DOWN	14		OPEN DISNEY+
07		CHANNEL UP / DOWN	15		OPEN PRIME VIDEO
08		MUTE	16		CHOOSE OR ADD AN ACCOUNT
08		INPUT			

RC PAIRING

When you first turn on your Google TV Device.
Pairing instructions will appear on the screen.


Please follow the pairing and setup instructions.

- 1. Press and hold the ← BACK + 🏠 (HOME) button to pair the remote control.



FIRST TIME SETUP

2. Select your desired language (ENGLISH is recommended)



3. Select Australia.

Select the country you are located in. Please note some apps, content, and/or features may not be available in all countries. Subject to availability.

4. You can quickly set up your streaming device using your Google Account on your smartphone.

Otherwise you may skip this feature and manually enter your wifi password to continue the setup process.

FIRST TIME SETUP (cont.)

4. Choose your Wi-Fi Network and enter in the password.

5. Sign in with your Google Account, if you do not have a Google Account, select “Skip”.

Note: You must have a Google Account to be able to access Google Play and download/install additional apps. With the software upgrade, some models do not provide the skip option.


6. Accept Terms of Service, Location (for weather and other user experiences).

7. **Choose a Device name:** BPTV30 or other suggestions.

GOOGLE TV - HOME

Once setup is completed, you will arrive at the Google TV home page.

Note: Below home page is **REFERENCE ONLY**.



GOOGLE TV - HOME (Cont.)

1. **PROFILE** - Select this option if you want to access: + Add or Manage Google Account
2. **FOR YOU** - Browse 400,000+ movies and TV episodes from across your streaming services — in one place, and organized by the genres and topics that interest you the most.
3. **MOVIES** - Watch your favorite movies or discover new favorites all in one place.
4. **SHOWS** - Watch your favorite shows or discover new favorites all in one place.
5. **APPS** - Download and access your favorite apps to discover movies, shows, games, and more.
6. **LIBRARY** - Keep all your shows and movies in a single watchlist. Add from your TV, phone, or browser - no matter which app its on.
7. **SEARCH** - Search for anything you are looking for.
8. **SETTINGS** - Manage settings including display and sound options.
9. **TOP PICK FOR YOU** - Discover movies and shows from across your apps inspired by what you've watched.
10. **YOUR APPS** - your pre-installed and downloaded apps. At the end of this row of apps, select the + box to add new apps you have downloaded and installed to your home screen.

GOOGLE ASSISTANT

Do more on your TV with your voice. Press the Google Assistant button on your remote to quickly search 400,000+ movies and shows, get recommendations to match your mood, control smart home devices, and more.

Monday in Homebush

Cloudy - Precip: 100% , Hum: 81% - More on weather.com

26°C

+ 21°

- 21°

Tue

23° 18°

Wed

23° 16°

Thu

23° 16°

Fri

23° 16°

Sat

23° 17°

Try saying...

What about this weekend


What about tomorrow

Always use Celsius

Always use Fahrenheit

GOOGLE ASSISTANT

Ask Google to search for the latest blockbuster, stream shows, or open multiplayer games. Have it dim the lights by connecting smart home devices. Manage tasks and see your calendar. Or ask it questions and see the answers on your TV.



“What’s the weather today?”



CUSTOMER SUPPORT:

info@ayonz.com
02 8279 8606

DISTRIBUTED BY:

Ayonz Pty Ltd